



PWT TREATED LVL VS PRESSURE TREATED LUMBER

PWT Treated LVL Features and Benefits

PWT Treated LVL used as a deck joist stays FLAT and STRAIGHT

- Your deck boards stay FLAT and STRAIGHT (reduce callbacks)

PWT Treated LVL has no top or bottom

- You do not need to “crown” your deck joists (labor savings)

Each piece of PWT Treated LVL is consistent in size

- You do not need to hand plane your deck joists to get a flat deck (labor savings)
- You can tape your joists on the ground before installation (labor savings)

PWT Treated LVL is stronger than dimensional lumber

- Longer spans eliminate mid-span beams and columns (material and labor savings)

PWT Treated LVL is a dry treatment, not pressure treated

- PWT Treated LVL is tighter than pressure-treated lumber (labor savings)

PWT Treated LVL comes with a 25-year warranty

- Your deck substructure needs to last as long as your deck boards



Scan for AIA CE Credits

